

HEAT PUMP THERMOSTATS - WHITE-RODGERS 70 SERIES THERMOSTATS

Single Stage	Multi-Stage	Heat Pump	Programs		Model	Applications				Thermostat Power Source*	Selectable Performance Features						Comfort and Convenience Features			Terminals
			Program Options	Periods Per Day Options		Model Number	Gas / Oil / Electric	3 Wire Zone Valve	Millivolt Compatible		Humidity Control (H)-Humidity / (D)-Dehumidify	Auto Changeover	Programmable Fan	Energy Mgt. Recovery	Keypad Lockout (T)-Total / (P)-Partial	Set-Point Temperature Limits Adjustable Max/Min	Indoor Remote Sensors Max. Number + Thermostat Average and/or Weighted	Outdoor Remote Sensor	Display Size Square inches	
		2/1	5+2	4	1F72-151	◆				H		✓					1.2	✓***	B	R, C, Y, W2, G, O/B, L, E
		2/1	∅	∅	1F79-111	◆				H							1.2	✓***	B	R, C, Y, W2, G, O/B, L, E

SINGLE STAGE THERMOSTATS - WHITE-RODGERS 70 SERIES THERMOSTATS

Single Stage	Multi-Stage	Heat Pump	Programs		Model	Applications				Thermostat Power Source*	Selectable Performance Features						Comfort and Convenience Features			Terminals
			Program Options	Periods Per Day Options		Model Number	Gas / Oil / Electric	3 Wire Zone Valve	Millivolt Compatible		Humidity Control (H)-Humidity / (D)-Dehumidify	Auto Changeover	Programmable Fan	Energy Mgt. Recovery	Keypad Lockout (T)-Total / (P)-Partial	Set-Point Temperature Limits Adjustable Max/Min	Indoor Remote Sensors Max. Number + Thermostat Average and/or Weighted	Outdoor Remote Sensor	Display Size Square inches	
1/1		1/1	5+2	4	1F78-151*	✓	✓		B		✓						1.2	✓***	B	RC, RH, W, Y, G, O, B
1/1		1/1	∅	∅	1F78-144*	✓	✓		B								1.2	✓***	B	RC, RH, W, Y, G, O, B
1/1			∅	∅	1E78-140	✓	✓		B								1.2	✓***	B	RH, W

* H = Hardwired (Requires Common)
B = Battery Powered

◆ Heat Pump for Stage 1, and Gas/Oil/Electric for 2nd Stage/Emergency
* Available in vertical style order 1E78-144/151
*** Optional Continuous Display Light w/ Hardwire connection



TECHNICAL HELP

- 1E78-151 Wiring Diagrams/Configuration See page 160
- 1F72-151 / 1F79-111 Wiring Diagrams/Configuration See page 161
- 1F78-144 / 1F78-111 Wiring Diagrams/Configuration See page 162